

▲12

Illustration Starter assy







Illustration Crankcase

C






▲34

Illustration Clutch assy




E




▲ 18

Illustration Handle and fuel tank



G



27 ■ KIT RIPARAZIONE
REPAIR KIT